

EMERGENCY ACTION PLAN

BASIN CREEK DAM No. 1 and No. 2

BUTTE-SILVER BOW DEPARTMENT OF PUBLIC WORKS WATER UTILITY DIVISION

July 2010

Emergency Action Plan Coordinator



EMERGENCY ACTION PLAN

BASIN CREEK DAMS #1 and #2

BUTTE-SILVER BOW DEPARTMENT OF PUBLIC WORKS WATER UTILITY DIVISION 124 WEST GRANITE STREET BUTTE, MONTANA 59703-0667 (406) 497-6540

July 2010

If Basin Creek Dam #1 is failing or failure seems imminent, call:

Butte-Silver Bow County Sheriff	911 or (406) 497-1120 Ext 1
Disaster and Emergency Services	(406) 497-6295
Mr. Roger Ebner	Home: (406) 723-2084
	Cel: (406) 490-5782
Mr. Dan Dennehy, Director of Public Works	
	Home: (406) 565-0358
	Cel: (406) 490-5802

TABLE OF CONTENTS

I.	INTRODUCTION
A	Purpose
В	Description of Dam
C	. Access to Dam
D	. Hazard Area
Ε	. Responsibility and Authority
F	Periodic Review/Update
II.	NOTIFICATION PROCEDURES
Α	. Imminent or Actual Failure4
В	. Potentially Hazardous Situation6
C	Posting of the Notification Flowchart and Distribution of the EAP
III.	MITIGATION ACTIONS
Α	. Potential Problems and Immediate Response Actions
В	. Emergency Supplies and Resources
C	. Local Contractors and Engineers
	LIST OF APPENDICES
API	PENDIX A – TECHNICAL DATA FOR DAMS #1 AND #2 A-1
API	PENDIX B – INUNDATION AND EVACUATION MAPS B-1
API	PENDIX C – TELEPHONE DIRECTORY
Δ 1D1	PENDIY D _ DAM INCIDENT REPORT FORM D-1

I. INTRODUCTION

A. Purpose

The purpose of this emergency action plan (EAP) is primarily to safeguard the lives of and secondarily to reduce property damage to the citizens of Silver Bow County living in or near the city of Butte, along Basin Creek, Silver Bow Creek and the Clark Fork River in the event of flooding caused by a failure of Basin Creek Dam #1 and/or Basin Creek Dam #2

B. Description of Dam

Basin Creek Dam #1 is in Silver Bow County, in Section 12, Township 1 North (T1N), Range 8 West (R8W), and located on Basin Creek, a tributary to Silver Bow Creek. It is owned by the Butte-Silver Bow Dept. of Public Works Water Utility Division, 124 West Granite Street, Butte, Montana 59701, and is used for municipal water supply for the Butte-Silver Bow area. Technical data pertaining to Basin Creek Dam #1 and its structures are shown in Appendix A.

Basin Creek Dam #2 is in Silver Bow County, in section 18, Township 1 North (T1N), Range (R7W), and located on Basin Creek, a tributary to Silver Bow Creek. It is owned by the Butte-Silver Bow Dept. of Public Works Water Utility Division, 124 West Granite Street, Butte, Montana 59701, and is used for municipal water supply storage for the Butte-Silver Bow area. Technical data pertaining to Basin Creek Dam #2 and its structures are shown in Appendix A

C. Access to Dam

Basin Creek Dam #1 is located at the end of Basin Creek Road, about 10 miles south of Butte. Note that the county road may become flooded! The nearest telephone to the dams is at the chlorinating building below the dam or at the home of Mr. Marty Hovan approximately ¼ mile below the dam.

D. Hazard Area

The evacuation area extends along Basin Creek, portions of the city of Butte, along Silver Bow Creek, and portions of areas along the Clark Fork River to a point about three miles south-east of Garrison, MT, as shown in Appendix B. Hazards include the possible inundation of occupied dwellings, Montana Rail Link Railroad, and Interstate Highway 15/90. Inundation and evacuation maps are in Appendix B.

E. Responsibility and Authority

Pursuant to the Dam Safety Act, Chapter 15 of Title 85, MCA, the dam owner is responsible for production, coordination, maintenance, and implementation of this emergency action plan. The extent of owner implementation was defined through coordination of this plan with the county sheriff and the disaster and emergency services (DES) coordinator.

F. Periodic Review/Update

The owner will review/update this EAP annually. Review/update by a qualified professional engineer will be accomplished as required by the dam's operating permit, but no less than every five years.

G. Approval

By my signature, I acknowledge that I, or my representative, have reviewed this plan and agree to the tasks and responsibilities assigned herein for my department and/or agency.

Signature Date

BUTTE-SILVER BOW CHIEF EXECUTIVE

Miema Trush Jane 15, 1995
Signature Date

DISASTER AND EMERGENCY SERVICES

John W Kuson June 16-1995 Signature Date

BUTTE-SILVER BOW SHERIFF'S DEPARTMENT

Signature Date

BUTTE-SILVER BOW FIRE CHIEF

Signature Date

DEER LODGE COUNTY SHERIFF'S DEPARTMENT

Signature Date


POWELL COUNTY SHERIFF'S DEPARTMENT

II. NOTIFICATION PROCEDURES

A. Imminent or Actual Failure

It is important that the you accurately judge whether the dam is about to fail. If you aren't sure whether the dam is threatened, seek advice from a qualified engineer or call the Dam Safety Section of the Department of Natural Resources and Conservation (DNRC). If Basin Creek Dam #1 is failing, two things must be done immediately: (1) the hazard area downstream from the dam must be evacuated, and (2) any steps that might save the dam or reduce damage to the dam or hazard area downstream should be taken. (Refer to the map in Appendix B to determine the areas that are likely to be inundated if the dam fails). The evacuation will be handled according to the EAP, and should be initiated as shown in Figure 1.

FIGURE 1 Basin Creek Dam #1or #2 ACTUAL OR IMMINENT FAILURE "NOTIFICATION FLOWCHART"




As dam owner, it is your responsibility to:

- 1) Call the Sheriff's Dispatch Center 911 or [(406) 497-1261] and Disaster and Emergency Services [(406) 497-6295]. Be sure to say, "This is an emergency." They will call other authorities and the media and begin evacuation.
- 2) Do whatever is necessary to bring anyone in immediate danger to safety. This includes someone on the dam, directly below the dam, or boating on the reservoir, or evacuees if so directed by the sheriff.
- 3) Keep in frequent touch with Disaster and Emergency Services staff. They will provide non-technical advice on how to handle the emergency.
- 4) If all means of communication are lost:
 - a. Try to find out why
 - b. Try to get to another radio or telephone that works
 - c. Get someone else to try to reestablish communications. If these means fail, handle the immediate problems as well as you can, and periodically try to reestablish contact with Disaster and Emergency Services.

B. Potentially Hazardous Situation

A potentially hazardous situation is an event or condition not normally encountered in the routine operation of the dam and reservoir. Among the unusual occurrences that may affect the dam are dam embankment problems, failure of the spillway or outlet works, heavy precipitation or rapid spring snow melt, landslides, earthquakes, erosion, theft, vandalism, acts of sabotage, and serious accidents. These occurrences may endanger the dam, the public, or the downstream valley and may necessitate a temporary or permanent revision of the dam's operating procedures. Help in these situations can be obtained by notifying those people shown in Figure 2.

FIGURE 2 Basin Creek Dam #1or #2 POTENTIALLY HAZARDOUS SITUATION "NOTIFICATION FLOWCHART"



- 1) If the dam owner discovers an unusual condition of the dam embankment that could threaten the structure:
 - a) Have a qualified engineer inspect the dam as soon as possible to determine whether emergency action is necessary.
 - b) Notify the county Disaster and Emergency Services Coordinator ((406) 497-6295) of the potential problem.
 - c) Contact the Dam Safety Section of the Department of Natural Resources and Conservation (DNRC).
- 2) Among the conditions the dam owner should watch for are:
 - a) Overtopping of the dam by flood waters
 - b) Loss of material from the dam crest due to storm wave erosion
 - c) Slides on either the upstream or downstream slope of the embankment as evidenced by
 - 1. Sloughing
 - 2. Cracking
 - 3. Bulging
 - 4. Scarping
 - d) Erosional flows through, beneath, or around the embankment as evidenced by
 - 1. Excessive seepage
 - 2. Discoloration of the seepage
 - 3. Boils on the downstream side
 - 4. Sinkholes
 - 5. Changes in the flow from drains
 - e) Failure of outlets or spillways due to clogging or erosion

- f) Movement of the dam on its foundation as evidenced by
 - 1. Misalignment
 - 2. Settlement
 - 3. Cracking
- 3) When the dam owner calls either an engineer or DNRC to report a problem, use the form in Appendix D to ensure you can provide sufficient information for the engineer to analyze the problems. In addition, prepare a sketch showing the extent of the problem. Revise the sketch periodically if the problem develops further. Section III includes further guidelines for courses of action to take to mitigate the effect of many problems.

C. Posting of the Notification Flowchart and Distribution of the EAP.

The Notification flowchart is posted at the dam of Basin Creek Dam #1 and a copy of the EAP is in the chlorination building just below the dam of the Basin creek #1. The Butte-Silver Bow County Sheriff's Office and the Silver Bow County DES Coordinator have copies of the plan.

III. MITIGATION ACTIONS

Besides normal monitoring of the dam's condition, which is done at least monthly, the owner will provide continuous monitoring and inspection during and after extreme events such as storms and earthquakes. Information on the magnitude of an earthquake or storm can be obtained from the National Weather Service. Actions are suggested below to mitigate problems that may develop, but those actions should never be continued at the risk of injury or at the expense of lessening efforts related to evacuation. Monitoring should identify any of the following potential problems.

A. Potential Problems and Immediate Response Actions

1) OVERTOPPING BY FLOOD WATERS

- a) Open outlet to its maximum safe capacity.
- b) Place sandbags along the crest to increase freeboard and force more water through the spillway and outlet.
- c) Provide erosion-resistant protection to the downstream slope by placing plastic sheets or other materials over eroding areas.
- d) Divert flood waters around the reservoir basin, if possible.
- e) Create additional spillway capacity by making a controlled breach in a low embankment or dike section where the foundation materials are erosion-resistant.

2) LOSS OF FREEBOARD OR DAM CROSS SECTION DUE TO STORM WAVE EROSION

- a) Place additional riprap or sandbags in damaged areas to prevent further embankment erosion.
- b) Lower the water level to an elevation below the damaged area.

3) SLIDES IN THE UPSTREAM OR DOWNSTREAM SLOPE OF THE EMBANKMENT

- a) Lower the water level at a rate and to an elevation considered safe, given the slope condition. If the outlet is damaged or blocked, pumping, siphoning, or a controlled breach may be required.
- b) Stabilize slides on the downstream slope by
- 4) Weighting the toe area with additional soil, rock, or gravel, and then
- 5) Restoring lost freeboard by placing sandbags at the crest.
- 6) EROSIONAL FLOWS THROUGH THE EMBANKMENT, FOUNDATION, OR ABUTMENTS
 - a) Plug the flow with whatever material is available (hay bales, bentonite, or plastic sheeting if the entrance to the leak is in the reservoir basin).
 - b) Lower the water level until the flow decreases to a non-erosive velocity or stops.
 - c) Place a protective sand-and-gravel filter or boil ring over the exit area to hold materials in place.

7) FAILURE OF APPURTENANT STRUCTURES SUCH AS OUTLETS OR SPILLWAYS

- a) Implement temporary measures to protect the damaged structure, such as closing an outlet or protecting a damaged spillway with riprap.
- b) Lower the water level to a safe elevation. If the outlet is inoperable, pumping, siphoning, or a controlled breach may be required.
- 8) MASS MOVEMENT OF THE DAM ON ITS FOUNDATION (SPREADING OR MASS SLIDING FAILURE)
 - a) Immediately lower the water level until excessive movement stops.
- 9) EXCESSIVE SEEPAGE AND HIGH LEVEL SATURATION OF THE EMBANKMENT
 - a) Lower the water to a safe level.

- a) Lower the water to a safe level.
- b) Continue frequent monitoring for signs of slides, cracking or concentrated seepage.

10) SPILLWAY BACKCUTTING, THREATENING RESERVOIR EVACUATION

- a) Reduce the flow over the spillway by fully opening the main outlet.
- b) Provide temporary protection at the point of erosion by placing sandbags, riprap materials, or plastic sheets weighted with sandbags.
- c) When the inflow subsides, lower the water to a safe level.

11) EXCESSIVE SETTLEMENT OF THE EMBANKMENT

- a) Lower the water level by releasing it through the outlet pumping, siphoning, or a controlled breach.
- b) If necessary, restore freeboard, preferably by placing sandbags.

B. <u>Emergency Supplies and Resources</u>

There is a supply of granular and clay types of soils located above and below the dam.

C. <u>Local Contractors and Engineers</u>

Local Contractors:

Jim Gilman Excavating Inc.,(406) 723-8234
In case of extreme emergency, end loaders, dozers, and other heavy equipment are available from
the following:
Silver Bow County Maintenance Shop, Butte,(406) 497-6565
Ask for Jocko Stajcar(406) 497-6569
Jocko Stajcar (home)(406) 782-3670

Engineers:

Butte-Silver Bow Water Utility Operations Manager: Rick Larson
Office(406) 497-6518
Home(406) 782-7673
Cel:(406) 490-1997
HKM Engineer: Dick Talley Butte, MT
Office(406) 723-8213
Home(406) 494-3043
Cel:(406) 491-1461
Pioneer Engineer: Brad Archibald Butte, MT
Office(406) 782-5177
Home(406) 494-6549
Cel:(406) 490-3032

APPENDICES

APPENDIX A TECHNICAL DATA FOR DAMS #1 AND #2

Technical Data for Basin Creek Dam #1

Maximum Reservoir Capacity to the Crest of the Dam:	1,170 acre fee
Normal Reservoir Capacity Measured to:	
Emergency Spillway Crest:	5 acre feet (gate up)
930 a	cre feet (gate down)
Normal Water Depth Measured from:	
Streambed to the Crest of the Emergency Spillway	79 feet (gate up)
7	5.5 feet (gate down)
Dam Height Measured from the Streambed to the Crest of the Dam:	80 fee
Dam Crest Width:	5 fee
Dam Width at Base:	120 fee
Length of Dam Crest:	275 feet
Outlet Capacity (Blow Off):	ubic feet per second
Design Capacity (Distribution Pipes)	ubic feet per second
Spillway Capacity (gate up) 23 c	ubic feet per second
Spillway Capacity	ubic feet per second
Date Constructed	1897
Slope of Upstream Face of Dam (Horizontal to Vertical)	vertical
Slope of Downstream Face of Dam (Horizontal to Vertical)	1 75.1

Technical Data for Basin Creek Dam #2

Maximum Reservoir Capacity to the Crest of Dam
Capacity Measured to the Emergency Spillway before breach
Normal Capacity Measured at Crest of Breech Channel
Water Depth Measured from the Streambed to the Crest of the emergency spillway 40 feet
Normal Water Depth Measured to Breech
Dam Height Measured from the Streambed to the crest of dam
Dam Crest Width
Dam Width at Base
Length of Dam Crest
Outlet Capacity
Spillway capacity
Date Constructed
Slope of Upstream Face of dam (Horizontal to Vertical)1:
Slope of Downstream face of Dam (Horizontal to Vertical)

APPENDIX B INUNDATION AND EVACUATION MAPS

c.f.s., and above Flint Creek, 17,500 c.f.s. Discharge but these locations were interpolated.

TABLE 1

Peak Discharges at

Various Distances Downstream of Basin Creek Dam #1

Clear Weather Breach

Montana Ouadrangle Mt. Humbug Mt. Humbug Mt. Humbug Butte South Homestake Butte South Butte North Ramsay Opportunity Opportunity	Distance Downstream from Dam (miles) Dam 0.2 0.9 3.6 7.8 12.4 17.0 21.4 25.4 30.9	Flood WSE (ft-msl) 5,870 5,782 5,745 5,645 5,526 5,446 5,367 5,289 5,173 5,004	Flood Discharge (cfs) 42,300 41,700 40,400 38,100 24,000 15,900 11,400 9,560 8,440 6,840 5,790	Time to Peak Discharge* (hr:min) 0:00 < 0:05 0:05 0:20 1:20 2:50 4:15 5:25 6:15 8:50 10:50
Opportunity Warm Springs Warm Springs	35.4	5,004 4,885 4,743	5,790 5,070	10:50 13:30

- * NOTE: The Time to Peak Discharge is the time from when the maximum flow is moving through the breached dam until the maximum flow occurs at the specified distance downstream. Substantial flooding, although it is not the maximum, will occur shortly before the specified time.
- ** NOTE: At approximately 37 miles downstream of Basin Creek Reservoir, peak discharge is less than the 100-year discharge for Clark Fork.

Ü

TABLE 2
Peak Discharges at
Various Distances Downstream of Basin Creek Dam #1
PMF with Breach

Montana Ouadrangle Mt. Humbug Mt. Humbug Mt. Humbug Mt. Humbug Butte South Homestake Butte South Butte North Ramsay Opportunity Opportunity Warm Springs Warm Springs Orofino Creek Orofino Creek Deer Lodge	Distance ownstream from Dam (miles) Dam 0.2 0.9 3.6 7.8 12.4 17.0 21.4 25.4 30.9 35.4 39.9 44.8 48.8 55.2	4,566 4,486	Flood Discharge (cfs) 118,000 117,000 110,000 102,000 73,500 50,600 36,600 36,600 26,800 21,800 18,600 15,900 12,700 11,400 10,300	Time to Peak Discharge* (hrs) 0:00 < 0:05 < 0:05 0:15 1:00 2:00 3:05 3:55 4:35 6:25 7:50 9:50 11:50 13:30 15:50
Deer Lodge Garrison **	55.2			


* NOTE: The Time to Peak Discharge is the time from when the maximum flow is moving through the breached dam until the maximum flow occurs at the specified distance downstream. Substantial flooding, although it is not the maximum, will occur shortly before the specified time.

** NOTE: At approximately 56 miles downstream of Basin Creek Reservoir, peak discharge is less than the 100-year discharge for Clark Fork.


CONCLUSIONS


1. General


The HEC-1 program was used to determine flood hydrographs and rating curves from the dam breach flood waves for the area below Basin Creek Dam #1. These flood wave hydrographs are shown in Figures 3 and 4. From the HEC-1 output, water surface elevations were calculated and flood inundation mapping was prepared which identifies downstream hazard areas. The flood





7.5 MII


























WARM SPRINGS QUADR MONTANA 7.5 MINUTE SERIES (TOPOG 361 47′ 30″ 1170 000 FEET 25 4886 Montana State Hospital Galen Campus 4756 4733 Modesty 4847 BM 473/ Wate 4860 4871 4877 39.9 miles from Basin Creek Dam 0 greek 8M 4764 AT THIS POINT THE CLEAR WEATHER BREACH DISCHARGE FALLS BELOW 100-YEAR FLOOD LEVELS All III 15


UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY







DMA 3476 IV SE-SERIES V894







UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY








UNITED STATES DEPARTMENT OF THE INTERIOR GEOLOGICAL SURVEY 112° 45′ 366000mE 368 42 8M4410 5150000mN 32 33 /<u>IT 9 N</u> /<u>IT 8 N</u> 5149 5 5148 4471 BAS 14 BM 4432 100 yr flood luvel. 5147 10 27' 30" 5146 BM 4443






APPENDIX C TELEPHONE DIRECTORY

Telephone Directory

A.	Priority C	<u>One</u>	
1.	EMERGI	ENCY NUMBER	911
	SHERIFF	F Silver Bow County911 or (9:00 A.M 5:00 P.M.) (406)	497-1120 Ext. 1
2.	DISASTE	ER AND EMERGENCY SERVICES	
	Silver Bo	ow CountyOffice:	(406) 497-6295
	EMERGE	ENCY NUMBER	911
	Mr. Roge	r EbnerHome:	(406) 723-2084
		Cel:	(406) 490-5782
	Montana	Disaster and Emergency Services Division (Helena)	(406) 841-3911
3.	EVACUE	EES (in upstream-to-downstream sequence)	
	Basin Cre	eek Residents in the flood plane area.	
	a.	Marty Hovan (Reservoir Operator - 670 Basin Creek Rd)	(406) 494-1775
	b.	Griff Davidson (634 Basin Creek Rd)	(406) 494-1312
	c.	Vacant (622 Basin Creek Rd)	(406) xxx-xxxx
	d.	Vacant/Removed (621 Basin Creek Rd)	(406) xxx-xxxx
	e.	Ralph Stodden (551 Basin Creek Rd)	(406) 494-4402
	f.	Wayne & Sandy Stodden (541 Basin Creek Rd)	(406) 494-1521
	g.	Nick & Judy Digiovine (245 Two Bit Rd)	(406) 494-1591
	h.	Jerry Piazzola (498 Basin Creek Rd)	(406) 494-1227
	i.	Kevin & Stacy Anderson (382 Basin Creek Rd)	(406) -782-4288
	j.	Jim Leary (381 Basin Creek Rd)	(406) 494-1396
	k.	Norma Anderson (373 Basin Creek Rd)	(406) 533-0064
	1.	Gary Wold (372 Basin Creek Rd)	(406) 782-6371
	m.	. Norma Anderson (371 Basin Creek Rd)	(406) 533-0064
	n.	Robert Neill (361 Basin Creek Rd)	(406) 494-4411
	o.	James Kissock (1179 Beacon Rd)	(406) 494-2612
	p.	Bill Gozden (319 Black Angus Ln)	Unlisted
	q.	Robert McDermott (515 Beacon Rd)	(406) 494-4158

	r.	John McDermott (203 Black Angus Ln)(4	06) 494-11	16
	s.	Terry Kivela (50 Apple Orchard Ln)(4	06) 723-85	33
	t.	Harvey & Sue Ellen Robertson (54 Apple Orchard Ln)(4	06) 494-31	14
	u.	Krag &Wetonia Filius (101 Beaver Pond)(4	06) 494-62	71
	v.	Kyle & Emily Stenson (103 Beaver Pond)(4	06) 494-82	25
	w.	Glen & Patti Rafish (108 Beaver Pond)(4	06) 723-46	47
	х.	Harry & Mildred Voss (110 Beaver Pond)(4	06) 533-08	90
	y.	Mark & Sue Stearns (214 Beacon Rd)(4	06) 494-76	25
	Z.	Louis & Linda Lovshin (12 Nickel Annie Ln) (4	06) 494-25	23
	aa.	. Ken Rustad (36 Nickel Annie Ln)(4	06) 494-26	01
	bb.	. Ken Rustad (58 Nickel Annie Ln) (4	06) 494-26	01
	cc.	Henry Beckman (5805 Albany))(4	06) 494-48	66
	dd.	. Roy & Connie Beckman (5800 Albany)) (4	06) 494-12	07
В.	Priority Tv	<u>wo</u>		
4.	LOCAL E	ENGINEERS		
	HKM Eng	ineering Inc(Office) (40	06) 723-82	13
	Dick Talle	ey(Home) (40	06) 494-30	43
	*************	(Cel) (40)6) 491-14	61
	Pioneer Te	echnical (Brad Archibald or Tim Hilmo)(Office) (40)6) 782-51	77
	Brad A	Archibald(Home) (40)6) 494-65	49
	********	(Cel) (40	06) 490-30	32
	5. MONT	TANA DEPARTMENT OF NATURAL RESOURCES AND CONSE	RVATION	:
	a.	Dam Safety Section Engineers:(Office) (406)	444-6613	
		Michele Lemieux Supervisor(Home) (406)	225-9062	
		(Cel) (406)	159-3572	

	b. Chad Newman (EAP Coordinator)(Office)(406)) 444-9362
	(Home)(406)) 442-9199
		(Cel) none
	c. Water Operations Bureau(Office) (406) 444-6816
	Laurence Siroky, Bureau Chief(Home) (406	5) 442-2806
	(Cel) (406	5) 431-7475
	d. Jim Beck, (Helena Regional Office)(Home) (406)) 444-6695
6.]	. NATIONAL WEATHER SERVICE	
	Missoula, MT(4	406) 329-4715
	Information(4	06) 329-4840
7.	BUTTE-SILVER BOW DEPARTMENT OF PUBLIC WORKS WATER UTII	LITY DIVISION
	Director of Public Works: Mr. Dan Dennehy,Office: (4	106) 497-6520
		106) 565-0358
		106) 490-5802
	Operations Manager: Mr. Rick Larson Office: (4	106) 497-6518
		106) 782-7673
	Cel: (4	106) 490-1997
3.	BUREAU OF LAND MANAGEMENT(4	106) 533-7600
€.	MONTANA DEPARTMENT OF STATE LANDS(4	106) 444-2074
10.). U.S. FOREST SERVICE, REGIONAL ENGINEERING OFFICE(4	06) 494-2147



APPENDIX D DAM INCIDENT REPORT FORM

DAM INCIDENT REPORT FORM

NAME OF DAM STREAM NAME LOCATION COUNTY OBSERVER OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS	DATE	TIME
STREAM NAME LOCATION COUNTY OBSERVER OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR ES SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	NAME OF DAM	
LOCATION COUNTY OBSERVER OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	STREAM NAME	
COUNTY OBSERVER OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	LOCATION	
OBSERVER OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	COUNTY	
OBSERVER TELEPHONE NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	OBSERVER	
NATURE OF PROBLEM LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR ES SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	OBSERVER TELEPHONE	
LOCATION OF PROBLEM AREA (Looking Downstream) EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR ES SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	NATURE OF PROBLEM	
EXTENT OF PROBLEM AREA FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR IS SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	LOCATION OF PROBLEM AREA (Looking Down	stream)
FLOW QUANTITY AND COLOR WATER LEVEL IN RESERVOIR ES SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	EXTENT OF PROBLEM AREA	
WATER LEVEL IN RESERVOIR S SITUATION WORSENING? EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS	FLOW QUANTITY AND COLOR	
EMERGENCY STATUS CURRENT WEATHER CONDITIONS ADDITIONAL COMMENTS		
EMERGENCY STATUSCURRENT WEATHER CONDITIONSADDITIONAL COMMENTS	IS SITUATION WORSENINGS	
ADDITIONAL COMMENTS		
ADDITIONAL COMMENTS	CURRENT WEATHER CONDITIONS	
	ADDITIONAL COMMENTS	